



1. All wood nailers to be approved material. Attachment of wood nailer to be accomplished by using fasteners providing no less than 200lb (556 N) of pullout. Fasteners shall be spaced no greater than 12" o.c. (305 mm).
2. When using GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner. Then apply GenFlex Primer.



**Gutter with Flange**

EPDM Systems

ACCEPTABLE SYSTEMS:  
Fully Adhered & Mechanically Attached

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION  
DATE:  
6-25-2015

DETAIL NO.  
**E-14.05**

NOT TO SCALE