



1. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner. Then apply GenFlex Primer.
2. All wood nailers to be approved material. Attachment of wood nailer to be accomplished by using fasteners providing no less than 200lb 890 N) of pullout. Fasteners shall be spaced no greater than 24" o.c. (610 mm).
3. Polymer batten strips cannot be used for attachments into brick, block, or concrete wall substrates. Use only on smooth surfaces, e.g. wood or insulation.

MAXIMUM WARRANTY: **20 Years**



**Tie-In to BUR with Cold Process or Asphalt**

EPDM Systems

ACCEPTABLE SYSTEMS:  
Fully Adhered & Mechanically Attached

ISSUE / REVISION  
DATE:

6-25-2015

NOT TO SCALE

DETAIL NO.

E-18.04