



1. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with 7" (178 mm) Peel & Stick. See Detail E-3.01.
2. Ensure that GenFlex Termination Bar is beneath coping.
3. Install GenFlex Bar Cover Tape prior to installing vertical termination bar.



Gravel Stop to Wall Flashing

EPDM Systems

ACCEPTABLE SYSTEMS:
All Systems

MAXIMUM WARRANTY: 10 Years	
ISSUE / REVISION DATE: 6-24-2015	DETAIL NO. E-3.11
NOT TO SCALE	