



1. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner. Then apply GenFlex Primer.
2. Apply a high profile bead of GenFlex Edge Caulk on the outside edge of the completed seam, allowing for 3" (76 mm) past overlap.



**Seam Tape End Lap Splice**

EPDM Systems

ACCEPTABLE SYSTEMS:  
All Systems

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION  
DATE:  
6-24-2015

NOT TO SCALE

DETAIL NO.  
**E-6.12**