



1. Compression fit details that incorporate GenFlex Water Stop must have all existing flashing removed to the bare substrate, e.g. masonry block.
2. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with 6" (152.40 mm) strip of FlexFlash E, or 7" (177.80 mm) Peel & Stick. See Detail E-3.01.
3. All parapet walls and roof curbs must be suitable for flashing, i.e. clean, tight, smooth, no cracks, etc.
4. Any approved pre-drilled fastener for curb and parapet terminations must have a minimum 125 lb (556.03 N) pullout. See approved fastener list.



10/06

**Wall Termination**

**Detail #: E-1.01**

**EPDM Systems**