



1. Compression fit details that incorporate GenFlex Water Stop must have all existing flashing removed to the bare substrate, e.g. masonry block.
2. Metal coping cap, expansion joint, and edge details are typical only. All metalwork should be installed to sheet metal codes (SMACNA). Clean all metal prior to installation of GenFlex materials.
3. Polymer batten strips cannot be used for attachments into masonry wall substrates. Use only on smooth surfaces, e.g. wood or insulation.
4. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with 6" (152.40 mm) strip of FlexFlash E, or 7" (177.80 mm) Peel & Stick. See Detail E-3.01.
5. All parapet walls and roof curbs must be suitable for flashing, i.e. clean, tight, smooth, no cracks, etc.



10/06

Wall Termination with Counter-Flashing

Detail #: E-1.02

EPDM Systems