

GenFlex Cured EPDM Membrane
See Note #3

GenFlex Fasteners
On Reroof Projects 8" (203.20 mm) o.c.
On New Construction 12" (304.80 mm) o.c.
with Neoprene / Metal Washer or Caulk
See Note #2

GenFlex Primer

1/4" (6.35 mm) or Less

GenFlex Water Stop Behind Edge of Flashing
See Note #1

GenFlex Termination Caulk

GenFlex Termination Bar

Bar Cover Tape

Gravel Stop or Edge Metal

1. Compression fit details that incorporate GenFlex Water Stop must have all existing flashing removed to the bare substrate, e.g. masonry block.
2. Any approved pre-drilled fastener for curb and parapet terminations must have a minimum 125 lb (556.03 N) pullout. See approved fastener list.
3. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with 6" (152.40 mm) strip of FlexFlash E, or 7" (177.80 mm) Peel & Stick. See Detail E - 3.01.

 **GenFlex**
Roofing Systems

10/06

Vertical Termination

Detail #: E-1.09

EPDM Systems