



1. Joint and precast must be filled to support membrane flashing fully.
2. This detail may also be used for vertical termination to span a control joint in any masonry substrate.



<p>Termination Bar at Joint in Precast Concrete Panel</p>	<p>Detail #: E-1.10</p>	<p>EPDM Systems</p>
--	--------------------------------	----------------------------