



1. All parapet walls and roof curbs must be suitable for flashing, i.e. clean, tight, smooth, no cracks, etc.
2. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with 6" (152.40 mm) strip of FlexFlash E, or 7" (177.80 mm) Peel & Stick. See Detail E-3.01.



10/06

Curb / Skylight / Roof Hatch with Backer Rod Termination	Detail #: E-3.06	EPDM Systems
---	-------------------------	---------------------