



1. When cured flashing is used on wall or curb flashing, vertical seams must be stripped-in at the base of angle change with 7" (177.80 mm) Peel & Stick. See Detail E-3.01.
2. Ensure that GenFlex Termination Bar is beneath coping.
3. Install GenFlex Bar Cover Tape prior to installing vertical termination bar.



Gravel Stop to Wall Flashing	Detail #: E-3.11	EPDM Systems
-------------------------------------	-------------------------	---------------------