



1. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner. Then apply GenFlex Primer.
2. You must apply a high profile bead of GenFlex Edge Caulk on the outside edge of the completed seam, allowing for 3" (76.20 mm) past overlap.



**Seam Tape End Lap Splice**

**Detail #: E-6.12**

**EPDM Systems**