



GenFlex TPO Reinforced Flashing or Field Cut TPO Membrane of Sufficient Width to Achieve a 1 1/2" (38.10 mm) Hot Air Weld onto the Deck Sheet and Extend Over Dam and Down to Cleat Bend on Metal Spring Cleat (Apply edge sealant to cut edges of membrane flashing to seal scrim after hot air welding the flashing to the deck membrane.)

Fasten Spring Cleat Assembly in Accordance with Manufacturer's Recommendations, But no Less Than 1 Fastener Every 6" (152.40 mm).



Snap On Two-Piece Fascia Assembly

Detail #: T-14.01

TPO Systems