



Refer to Details T-6.01 through T-6.04 and the Mechanically Attached TPO Matrix in the design section of this manual to determine proper securement type, alignment, and spacing. **Special alignment procedures are in effect for FM 1-90 compliant systems using 8', 10', or 12' (3.66 m) wide TPO panels.**



<b>TPO Panel Markings</b>	<b>Detail #: T-6.05</b>	<b>TPO Systems</b>
---------------------------	-------------------------	--------------------