



1. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex EPDM Cleaner, then apply GenFlex Primer.
2. Apply GenFlex Edge Caulk around entire perimeter of GenFlex T-Joint Cover and along seams for 6" (152 mm) past intersection.



T-Joint/Seam Intersection Cover

EPDM Systems

ACCEPTABLE SYSTEMS:
All Systems

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION DATE:
6-24-2015
NOT TO SCALE

DETAIL NO.
E-6.10