



- NOTE:
1. REFER TO GENFLEX™ WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. HOLE IN MEMBRANE SHOULD EXTEND A MINIMUM OF 1/2" (13 mm) BEYOND CLAMPING RING AND SHOULD NOT BE SMALLER THAN THE DIAMETER OF THE LEADER PIPE.
 3. INSULATION ADJACENT TO DRAIN TO BE APPROPRIATE ELEVATE INSULATION WITH APPROPRIATE BONDING SURFACE.
 4. GENFLEX WATERSTOP MIN 1/2 OF 10 OZ. (295 ml) TUBE PER 4" DRAIN. USE ADDITIONAL WATERSTOP FOR LARGER DRAINS.
 5. IN RE-ROOF APPLICATIONS:
 - REMOVE EXISTING FLASHING DOWN TO METAL BOWL.
 - REPAIR OR REPLACE BROKEN DRAIN COMPONENTS.
 - DRILL AND TAP BROKEN DRAIN BOLTS AND REPLACE IF NECESSARY.

SUMP AREA FIELD SEAM REQUIREMENTS.

- A. IF FIELD SEAM EDGE IS WITHIN 9" (229 mm) OF DRAIN COMPRESSION RING, EPDM TARGET PATCH IS REQUIRED.
- B. IF FIELD SEAM EDGE IS WITHIN 9" (229 mm) TO 18" (457 mm) OF DRAIN COMPRESSION RING, INSTALL A LAYER OF 6" COVER TAPE CENTERED OVER SEAM EDGE. FLASHING MUST EXTEND 3" (76 mm) MIN. BEYOND EDGE OF SUMP TAPERED AREA.



ROOF DRAIN

ACCEPTABLE SYSTEMS: EZ EPDM PEEL & STICK™ SELF ADHERED

(800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION DATE:
07/28/2023

DETAIL NO.
EZE-PS-D-01

NOT TO SCALE