



- NOTE:
1. REFER TO GENFLEX™ WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. REMOVE ALL EXISTING FLASHING, LEAD, ETC. PIPE SURFACE MUST BE FREE OF ALL RUST, GREASE, INSULATION, ETC.
 3. PIPE MUST BE ANCHORED TO ENSURE STABILITY.
 4. APPLY EDGE CAULK AROUND ENTIRE PERIMETER OF FLASHING. REFER TO EZE-PS-LS-09 FOR SEAM EDGE TREATMENT.
 5. DO NOT USE WHEN SERVICE LINE TEMPERATURE EXCEEDS 180 °F (82 °C) . REFER TO EZE-PS-P-04.



PENETRATION WITH FIELD FABRICATED FLASHING

ACCEPTABLE SYSTEMS: EZ EPDM PEEL & STICK™ SELF ADHERED

(800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION DATE:
07/28/2023

NOT TO SCALE

DETAIL NO.
EZE-PS-P-03