



NOTE:

1. REFER TO GENFLEX™ WEBSITE FOR THE MOST CURRENT INFORMATION.
2. ALLOW 1/4" (6 mm) MAX. SPACE BETWEEN SECTIONS OF DRAIN BAR.
3. DO NOT PRE-NAIL MEMBRANE TO THE FACE OF THE WOOD NAILER.
4. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES.
5. IF METAL COUNTER-FLASHING EXCEEDS 4" (102 mm) IN WIDTH, A CONTINUOUS CLEAT MUST BE INSTALLED.
6. TERMINATION BAR AND STAINLESS STEEL FASTENERS MAY BE USED IN LIEU OF GENFLEX DRAIN BAR FOR THE PEEL & STICK MEMBRANE.



ROOF EDGE WITH DRAIN BAR

ACCEPTABLE SYSTEMS: EZ EPDM PEEL & STICK™ SELF ADHERED

(800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION DATE:

07/28/2023

NOT TO SCALE

DETAIL NO.

EZE-PS-RE-05