



**NOTE:**

1. All parapet walls and roof curbs must be suitable for flashing, e.g. clean, tight, smooth, no cracks, etc. and be primed with GenFlex Clear Primer.
2. Polymer batten strips cannot be used for attachments into brick, block, or concrete wall substrates. Use only on smooth surfaces, e.g. wood or insulation.
3. Apply GenFlex TPO Edge Caulk to all seam and flashing edges.

**REFER TO DETAIL EZ-S-6.01 FOR SEAMING OPTIONS**

MAXIMUM WARRANTY: <b>20 Years</b>	
ISSUE / REVISION DATE: 10/19/2021	DETAIL NO. <b>EZ-S-4.02</b>
NOT TO SCALE	



**Inside Corner Flashing with TPO Flashing Kit Material**

GenFlex EZFlex Peel & Stick™ TPO Systems

ACCEPTABLE SYSTEMS:  
Self Adhered