

- 1. All parapet walls and roof curbs must be suitable for flashing, e.g. clean, tight, smooth, no cracks, etc.
- 2. Polymer batten strips cannot be used for attachment into brick, block, or concrete wall substrates. Use only on smooth surfaces, e.g. wood or insulation.

**EPDM Systems** 

<b>TGEN</b>	FLEX
	Roofing Systems

Basewall Expansion Joint

ACCEPTABLE SYSTEMS:
Fully Adhered & Mechanically Attached

MAXIMUM WARRANTY: **20 Years**ISSUE / REVISION DETAIL NO.

6-24-2015

DATE:

NOT TO SCALE

E-11.04