

- 1. All wood nailers to be approved material. Attachment of wood nailer to be accomplished by using fasteners providing no less than 200lb (556 N) of pullout. Fasteners shall be spaced no greater than 12" o.c. (305 mm).
- 2. When using GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner, then apply GenFlex Primer.

EPDM Systems

TO ENIELEY	
GEINLTEY	
Roofing Systems	ı

Gravel Stop/Edge Lap Joint

ACCEPTABLE SYSTEMS:

All Systems

ISSUE / REVISION DATE:

6-25-2015

DETAIL NO.

E-14.09

MAXIMUM WARRANTY: 20 Years