



1. Metal coping cap, expansion joint, and edge details are typical only. All metalwork should be installed to sheet metal codes (SMACNA). Clean all metal prior to installation of GenFlex materials.
2. All wood nailers to be approved material. Attachment of wood nailer to be accomplished by using fasteners providing no less than 200lb (556 N) of pullout. Fasteners shall be spaced no greater than 12" o.c. (305 mm).
3. For seams assembled with GenFlex G-400 Seam Adhesive, a bead of GenFlex Edge Caulk is required on all exposed edges, following a pre-cleaning of the seam area with GenFlex Cleaner.
4. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner, then apply GenFlex Primer.



**Curb Tie-In**

EPDM Systems

ACCEPTABLE SYSTEMS:  
All Systems

MAXIMUM WARRANTY: **20 Years**

ISSUE / REVISION  
DATE:  
6-25-2015

NOT TO SCALE

DETAIL NO.

**E-18.02**