

1. Remove all existing stone, and thoroughly clean.
2. GenFlex Roofing Systems is not responsible for damage to BUR.
3. All wood nailers to be appi
4. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex Cleaner, then apply GenFlex Primer.