



1. All parapet walls and roof curbs must be suitable for flashing, e.g. clean, tight, smooth, no cracks, etc.
2. When using GenFlex Seam Tape and GenFlex Bar Cover Tape, first clean the membrane with GenFlex EPDM Cleaner, then apply GenFlex Primer.
3. For seams assembled with GenFlex G-400 Seam Adhesive, a bead of GenFlex Edge Caulk is required on all exposed edges, following a pre-cleaning of the seam area with GenFlex EPDM Cleaner.
4. Polymer batten strips cannot be used for attachments into masonry wall substrates. Use only on smooth surfaces, e.g. wood or insulation.



**Field Fabricated Inside Corner**

EPDM Systems

ACCEPTABLE SYSTEMS:  
All Systems

**MAXIMUM WARRANTY: 10 Years**

ISSUE / REVISION  
DATE:  
6-24-2015

NOT TO SCALE

DETAIL NO.

**E-4.02**