

- 1.Installed sections of GenFlex TPO Walkway Pads should not exceed 10' (3 m) in length. Allow for a 4" (102 mm) space between ends of adjacent sections of walkway pad.
- 2. When using GenFlex FlexWhite Seam Tape, first apply FlexWhite Clear Primer to the FlexWhite EPDM field sheet and to the underside of the TPO Walkway Pad where the seam tape will bond. Apply the primer using a GenFlex Scrub Pad & Handle.

EPDM Systems

TCENELEY
APIAI PPV
Roofing Systems

Installation of Walkway Pad	

ACCEPTABLE SYSTEMS:
All Systems

MAXIMUM WARRANTY: **20 Years**ISSUE / REVISION DETAIL NO.

6-25-2015

NOT TO SCALE

FW-16.05