



Night Seal Installation Instructions - For use at the end of the workday and as required by inclement weather:

1. Extend the deck membrane 12" (305 mm) past the edge of the new insulation.
2. Clean the substrate at the night seal location to remove any dirt or debris. The seal you achieve can only be as good as your cleaning.
3. Apply GenFlex Primer to the last 2" (51 mm) of the top of the deck sheet and the last 5" (127 mm) of the bottom of the deck sheet, and allow to flash-off.
4. Set the last 5" (127 mm) of deck membrane into a 5" (127 mm) wide bead of Pourable Sealer. The membrane should be 1" (25mm) back from the edge of the Pourable Sealer in order to allow for the membrane edge to be enveloped in the sealer.
5. Install a 2" x 4" (51 mm x 102 mm) 1" (25.40 mm) away from the membrane edge, and secure to the deck 24" o.c. (610 mm), compressing the membrane into the Pourable Sealer.
6. Trowel Pourable Sealer over the exposed 1" (25.40 mm) of membrane, enveloping the membrane edge.
7. Upon return to work, remove the 2" x 4" (50.80 mm x 101.60 mm), cut the last 6" (152.40 mm) off the deck sheet, and discard. Then proceed with roofing operations.