



1. Prime the backside of the TPO membrane with Clear Primer prior to attaching to the RMA strip.
2. GenFast Purlin Fasteners must penetrate the structural purlin a minimum of 1.5" (38 mm) total.
3. If structural purlins are spaced every 5' (1.5 m), fastener spacing is not to exceed 12" (305 mm) o.c. If structural purlins are spaced every 6' (1.8 m), fastener spacing is not to exceed 6" (152 mm) o.c.