



SUMP AREA FIELD SEAM REQUIREMENTS:

- A. IF SEAM EDGE IS WITHIN 9" (229 mm) OF DRAIN COMPRESSION RING, EPDM TARGET PATCH REQUIRED.
- B. IF SEAM EDGE IS WITHIN 9" (229 mm) TO 18" (457 mm) OF DRAIN COMPRESSION RING, INSTALL A LAYER OF 7" (178 mm) PEEL & STICK FLASHING CENTERED OVER SEAM EDGE, FLASHING MUST EXTEND 3" (76 mm) MIN. BEYOND EDGE OF SUMP.

- NOTE:
1. REFER TO GENFLEX WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. HOLE IN MEMBRANE SHOULD EXTEND A MINIMUM OF 1/2" (13 mm) BEYOND CLAMPING RING AND SHOULD BE LARGER THAN THE DIAMETER OF THE LEADER PIPE.
 3. INSULATION ADJACENT TO DRAIN TO BE APPROPRIATE GENFLEX INSULATION WITH APPROPRIATE BONDING SURFACE.
 4. GENFLEX WATERSTOP MIN 1/2 OF 10 oz (295 ml) TUBE PER 4" DRAIN. USE ADDITIONAL WATERSTOP FOR LARGER DRAINS.
 5. FOLLOW DRAIN INSERT INSTALLATION INSTRUCTIONS (INCLUDED IN DRAIN INSERT PACKAGE) FOR SPECIFIC GUIDELINES, RECOMMENDATIONS, AND REQUIREMENTS.



GENFLEX DRAIN INSERT

GENFLEX™

ACCEPTABLE SYSTEMS: **SEAM2SEAM™ EPDM**

GENFLEX: (800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION DATE:

04/06/2020

NOT TO SCALE

DETAIL NO.

S2S-D-3