



**NOTE:**

1. REFER TO GENFLEX WEBSITE FOR THE MOST CURRENT INFORMATION.
2. REMOVE ALL EXISTING FLASHING, LEAD, ETC. PIPE SURFACE MUST BE FREE OF ALL RUST, GREASE, INSULATION, ETC.
3. PENETRATION AND SLEEVE MUST BE ANCHORED TO ENSURE STABILITY.
4. APPLY SEAM2SEAM SEALANT AROUND ENTIRE PERIMETER OF FLASHING. REFER TO S2S-LS-9 FOR SEAM2SEAM EDGE TREATMENT.
5. ADDITIONAL MEMBRANE SECUREMENT REQUIRED WHEN PENETRATION EXCEEDS 12" (305 mm) DIAMETER. REFER TO BT DETAILS.



**PENETRATION (HOT STACK) WITH  
FIELD FABRICATED FLASHING**

**GENFLEX™**

ACCEPTABLE SYSTEMS: **SEAM2SEAM™ EPDM**

GENFLEX: (800) 443-4272 www.genflex.com

**MAXIMUM WARRANTY:** 20 Years

ISSUE / REVISION  
DATE:

04/06/2020

NOT TO SCALE

DETAIL NO.

**S2S-P-4**