



- NOTE:**
1. REFER TO GENFLEX WEBSITE FOR THE MOST CURRENT INFORMATION.
 2. APPLY SEAM2SEAM SEALANT ALONG ENTIRE PERIMETER OF T-JOINT COVER. REFER TO S2S-LS-9 FOR SEAM EDGE TREATMENT.
 3. SEAM2SEAM SEALANT IS REQUIRED ALONG ENTIRE UPSLOPE EDGE OF PEEL&STICK FLASHING WHEN ROOF SLOPE IS 1" (25 mm) PER FOOT OR GREATER.
 4. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING CODES OR 200 lb PER LINEAR FOOT IN ANY GIVEN DIRECTION.
 5. FLANGE OF METAL MUST BE FULLY SUPPORTED BY WOOD AND TERMINATED AT LEAST 1/2" (13 mm) FROM EDGE OF WOOD.
 6. USE ACCEPTABLE GENFLEX PRIMER TO CLEAN AND PRIME EPDM MATING SURFACES PRIOR TO INSTALLATION OF PEEL & STICK PRODUCTS.



**ROOF EDGE PEEL & STICK FLASHING
AT FIELD SEAM**

GENFLEX™
ACCEPTABLE SYSTEMS: **SEAM2SEAM™ EPDM**

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION
DATE:

06/12/2020

DETAIL NO.

S2S-RE-27

GENFLEX: (800) 443-4272 www.genflex.com

NOT TO SCALE