

## NOTE:

- 1. REFER TO GENFLEX WEBSITE FOR MOST CURRENT INFORMATION.
- 2. ROUND ALL SHEET METAL FLANGE CORNERS.
- 3. APPLY SEAM2SEAM SEALANT AROUND ENTIRE PERIMETER OF FLASHING. REFER TO S2S-LS-9 FOR PEEL & STICK EDGE TREATMENT.
- 4. SEE S2S-S-4A, S2S-S-4B & S2S-S-4C FOR DETAILED INSTALLATION INSTRUCTIONS.

CENFLEX (NON-WELDED SLEEVE)

GENFLEX™ ACCEPTABLE SYSTEMS: SEAM 2 SEAM 2