

## NOTE:

- 1. REFER TO GENFLEX WEBSITE FOR MOST CURRENT INFORMATION.
- 2. INSTALL GENFAST TERMINATION BAR WITH 1/4" (6 mm) GAP BETWEEN ADJOINING SECTIONS.
- 3. TERMINATION BAR MUST BE CUT AT INSIDE AND OUTSIDE CORNERS. **DO NOT BEND AROUND CORNERS**.
- 4. TERMINATION BAR MUST BE FASTENED WITHIN 1" (25 mm) MAX. OF ALL SECTION ENDS.
- 5. APPLY WATERSTOP IN A 3/8" (10 mm) TO 1/2" (13 mm) BEAD AT APPROXIMATELY 10 LF PER TUBE.

|   | TERMINATION WITH TERMINATION BAR |                                      | MAXIMUM WARRANTY: 20 Years |            |
|---|----------------------------------|--------------------------------------|----------------------------|------------|
| GENFLEX                                 |                                  |                                      | ISSUE / REVISION<br>DATE:  | DETAIL NO. |
|   | GENFLEX™                         | ACCEPTABLE SYSTEMS: SEAM 2 SEAM EPDM | 04/06/2020                 | S2S-T-1    |
| GENFLEX: (800) 443-4272 www.genflex.com |                                  |                                      | NOT TO SCALE               | 020 1 1    |