



NOTE:

1. REFER TO GENFLEX™ WEBSITE FOR THE MOST CURRENT INFORMATION.
2. HOLE IN MEMBRANE SHOULD EXTEND A MINIMUM OF 1/2" (13 mm) BEYOND CLAMPING RING AND SHOULD NOT BE SMALLER THAN THE DIAMETER OF THE LEADER PIPE.
3. GENFLEX WATERSTOP MIN 1/2 OF 10 OZ. (295 ml) TUBE PER 4" DRAIN. USE ADDITIONAL WATERSTOP FOR LARGER DRAINS.
4. IN RE-ROOF APPLICATIONS:
 - REMOVE EXISTING FLASHING DOWN TO METAL BOWL.
 - REPAIR OR REPLACE BROKEN DRAIN COMPONENTS.
 - DRILL AND TAP BROKEN DRAIN BOLTS AND REPLACE IF NECESSARY.

FIELD SEAM REQUIREMENTS.

- A. IF FIELD SEAM EDGE IS WITHIN 9" (229 mm) OF DRAIN COMPRESSION RING, EPDM TARGET PATCH REQUIRED.
- B. IF FIELD SEAM EDGE IS WITHIN 9" (229 mm) TO 18" (457 mm) OF DRAIN COMPRESSION RING, INSTALL A LAYER OF 6" COVER TAPE CENTERED OVER SEAM EDGE, FLASHING MUST EXTEND 3" (76 mm) MIN. BEYOND EDGE OF SUMP TAPERED AREA.



OVERFLOW ROOF DRAIN WITH WATER DAM

ACCEPTABLE SYSTEMS: EZ EPDM PEEL & STICK™ SELF ADHERED

(800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION DATE:
07/28/2023

NOT TO SCALE

DETAIL NO.
EZE-PS-D-02