



**SUMP AREA FIELD SEAM REQUIREMENTS.**

- A. IF FIELD SEAM EDGE IS WITHIN 9" (229 mm) OF DRAIN COMPRESSION RING, EPDM TARGET PATCH REQUIRED.
- B. IF FIELDS SEAM EDGE IS WITHIN 9" (229 mm) TO 18" (457 mm) OF DRAIN COMPRESSION RING, INSTALL A LAYER OF 6" COVER TAPE CENTERED OVER SEAM EDGE, FLASHING MUST EXTEND 3" (76 mm) MIN. BEYOND EDGE OF SUMP TAPERED AREA..

- NOTE:
- 1. REFER TO GENFLEX™ WEBSITE FOR THE MOST CURRENT INFORMATION.
  - 2. HOLE IN MEMBRANE SHOULD EXTEND A MINIMUM OF 1/2" (13 mm) BEYOND CLAMPING RING AND SHOULD NOT BE SMALLER THAN THE DIAMETER OF THE LEADER PIPE.
  - 3. INSULATION ADJACENT TO DRAIN TO BE APPROPRIATE GENFLEX INSULATION WITH APPROPRIATE BONDING SURFACE.
  - 4. GENFLEX WATERSTOP MIN 1/2 OF 10 OZ. (295 ml) TUBE PER 4" DRAIN. USE ADDITIONAL WATER STOP FOR LARGER DRAINS.
  - 5. FOLLOW DRAIN INSERT INSTALLATION INSTRUCTIONS (INCLUDED IN DRAIN INSERT PACKAGE) FOR SPECIFIC GUIDELINES, RECOMMENDATIONS, AND REQUIREMENTS.



**DRAIN INSERT**

ACCEPTABLE SYSTEMS: EZ EPDM PEEL & STICK™ SELF ADHERED

(800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION DATE:  
07/28/2023

NOT TO SCALE

DETAIL NO.  
**EZE-PS-D-03**