



NOTE:

1. REFER TO WWW.GENFLEX.COM FOR MOST CURRENT INFORMATION.
2. THIS DETAIL SHOULD BE USED ONLY WHERE THE DECK IS SUPPORTED BY THE OUTSIDE WALL.
3. WOOD NAILERS MUST BE INSTALLED WITH SUITABLE FASTENERS TO MEET APPLICABLE BUILDING CODES.
4. ALL SHEET METAL IS TO BE INSTALLED PER SMACNA GUIDELINES. TPO COATED METAL IS ACCEPTABLE WHEN INSTALLING TPO WALL FLASHING.
5. GRANULES MUST BE EMBEDDED WHEN THERMALLY FUSING GRANULE SURFACED CAP SHEET.
6. FLASHING LAPS MUST BE OFFSET FROM FIELD LAPS BY A MINIMUM OF 12" (305 mm). PARAPETS WITH NAILABLE SUBSTRATES MUST HAVE A GENFLEX BASE SHEET MECHANICALLY ATTACHED IN ACCORDANCE WITH THE FOLLOWING SPACING:
 UP TO 24" (305-610 mm) 9" (152 mm) ON CENTERS
 24-36" (610-914 mm) 6" (228 mm) ON CENTERS
 FIELD OF WALL ONE PER FT² (929 cm²)
7. FLEXWHITE SEAM TAPE IS ACCEPTABLE WHEN INSTALLING TPO WALL FLASHING. USE APPROPRIATE PRIMER.



**CURB/WALL FLASHING USING
AFR EPDM/EZ TPO MEMBRANE**

GENFLEX™

ACCEPTABLE SYSTEMS: **MODIFIED BITUMEN**

GENFLEX: (800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION
DATE:

05/07/2025

NOT TO SCALE

DETAIL NO.

MB-BT-10