



**NOTE:**

1. REFER TO [WWW.GENFLEX.COM](http://WWW.GENFLEX.COM) FOR MOST CURRENT INFORMATION.
2. WOOD NAILERS MUST BE INSTALLED WITH SUITABLE FASTENERS TO MEET APPLICABLE BUILDING CODES.
3. ALL SHEET METAL IS TO BE INSTALLED PER SMACNA GUIDELINES.
4. GRANULES MUST BE EMBEDDED WHEN THERMALLY FUSING GRANULE SURFACED CAP SHEET.
5. WHEN POSSIBLE, MECHANICAL UNITS SHOULD NOT BE SET UNTIL THE ROOF MEMBRANE AND FLASHING HAVE BEEN INSTALLED.

**THIS DETAIL APPLIES  
TO SBS MEMBRANES ONLY**



**ULTRAFLASH CURB**

**GENFLEX™**

ACCEPTABLE SYSTEMS: **MODIFIED BITUMEN**

GENFLEX: (800) 443-4272 [www.genflex.com](http://www.genflex.com)

**MAXIMUM WARRANTY: 20 Years**

ISSUE / REVISION  
DATE:

**05/07/2025**

NOT TO SCALE

**DETAIL NO.**

**MB-BT-15**