## NOTE

- 1. REFER TO WWW.GENFLEX.COM FOR THE MOST CURRENT INFORMATION.
- 2. PROPERLY CLEAN SURFACE OF LOOSE GRAVEL.GRANULES, AND OTHER CONTAMINANTS PRIOR TO APPLYING NEW MEMBRANE.
- 3. GRANULES MUST BE EMBEDDED WHEN THERMALLY FUSING GRANULE SURFACED CAP SHEET.



