

Diagram illustrating the first step of the installation process. A square panel with rounded corners is shown. A center point is marked with a starburst symbol. A horizontal dimension line indicates a distance of 4" (102 mm) from the center point to the right edge of the panel. The text "STEP 1" is written below the panel.

STEP 2

STEP 3

2" (51 mm) MIN

STEP 3

SUBSTRATE

PENETRATION

SUBSTRATE

1. REFER TO WWW.GENFLEX.COM FOR MOST CURRENT INFORMATION.
2. PRIME ALL NON POROUS SURFACES WITH ULTRAFLASH PRIMER.
3. ULTRAFLASH LIQUID FLASHING SHOULD BE APPLIED WITH A BOTTOM COAT OF 30 mil WET THICKNESS AND A TOP COAT OF 60 mil WET THICKNESS.
4. APP REQUIRES ONE-PART ULTRAFLASH (PRIMER NOT REQUIRED).

