



NOTE:

1. REFER TO [WWW.GENFLEX.COM](http://WWW.GENFLEX.COM) FOR MOST CURRENT INFORMATION.
2. WOOD NAILERS MUST BE INSTALLED WITH SUITABLE FASTENERS TO MEET APPLICABLE BUILDING CODES (MIN 200 lb PER LINEAR FOOT IN ANY GIVEN DIRECTION).
3. ALL SHEET METAL IS TO BE INSTALLED PER SMACNA GUIDELINES.
4. PRIME ALL METAL AND MASONRY SURFACES TO BE FLASHED WITH ULTRAFLASH PRIMER.



**ULTRAFLASH SCUPPER**

**GENFLEX™**

ACCEPTABLE SYSTEMS: **MODIFIED BITUMEN**

GENFLEX: (800) 443-4272 [www.genflex.com](http://www.genflex.com)

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION  
DATE:

05/21/2025

NOT TO SCALE

DETAIL NO.

**MB-S-2**