



**NOTE:**

1. REFER TO THE GENFLEX™ WEBSITE FOR MOST CURRENT INFORMATION.
2. WOOD NAILER MUST BE INSTALLED TO MEET APPLICABLE BUILDING.
3. FLEXWHITE PEEL & STICK FLASHING SHALL BE POSITIONED TO EXTEND MIN 2" (50.8 mm) ONTO ROOF MEMBRANE BEYOND EDGE OF METAL CURB FLANGE.
4. 12" (304.8 mm) FLEXWHITE PEEL & STICK FLASHING SHALL BE CENTERED OVER 6" (152.4 mm) FLEXWHITE PEEL & STICK FLASHING SO THAT IT EXTENDS MIN 2" (50.8 mm) BEYOND EDGE OF 6" (152.4 mm) FLASHING.
5. REFER TO CUT EZT-C-02 FOR OUTSIDE CORNER APPLICATION.
6. WOOD NAILER TO MATCH THE HEIGHT OF THE INSULATION SYSTEM.

**WARRANTY MEMBRANE REQUIREMENTS:**

**15-YEAR**  
TPO - 45 MIL  
**20-YEAR**  
TPO - 60 MIL



**BASE TIE-IN AT WELDED WATERTIGHT CURB  
(FLANGES UNDER 2")**

MATERIAL: EZ TPO

ACCEPTABLE SYSTEMS: ALL

GENFLEX: (800) 443-4272 www.genflex.com

MAXIMUM WARRANTY: 20 Years

ISSUE / REVISION  
DATE:

04/14/2026

NOT TO SCALE

DETAIL NO.

**EZT-BT-12**