

# Product Data Sheet



## GenFast™ Termination Bar

Item Description	Item Number
1.25" (32 mm) x 10" (3 m)	W590010088
1.25" (32 mm) x 5" (1.5 m)	W590051239
<i>*50 bars per tube</i>	

### Description

GenFast Termination Bar is a corrosion resistant aluminum material used for terminating and sealing membrane wall flashings to various approved substrates as outlined by current GenFlex Specifications and Details.

### Method of Application

Refer to current GenFlex Technical Specifications for additional instructions.

1. Substrates must be free from dust, dirt, oil, water, and other contaminants (wall areas above termination bar must not pass water). Install per current GenFlex specifications.
2. Apply GenFlex WaterStop behind flashing membrane.
3. Install flat side of bar towards flashing so "lip" is facing upwards and forms a wide reservoir for edge caulk.
4. Anchor bar through pre-punched holes at a rate to maintain a seal to the wall against WaterStop - Max. 12" o.c. (304.8 mm).
5. Remove excess flashing material above bottom of lap sealant reservoir channel.
6. Install GenFlex Termination Caulk into reservoir channel.

### Storage

- Termination Bar should be protected from moisture and kept dry at all times.
- If stored out of doors, place on skids in a dry area and cover with a breathable tarp.

### Precautions

- Do not use as a bar anchor.
- Where field cutting is necessary, remove any burrs from bar.
- Clean up shavings, etc., that may occur from field cutting.
- Install flat side of bar towards flashing so "lip" is facing upwards and forms a wide reservoir for edge caulk.
- Keep a space of ¼" (6 mm) between each length of GenFlex Termination Bar.
- GenFlex Termination Bars must be installed directly to the wall surface, not existing sheet metal, flashings, etc.
- Install GenFlex Termination Bar on hard, smooth surfaces only. Do not install on substrates where seal is lost at mortar joints, etc.
- Install GenFlex Termination Bar Vertically where base flashing(s) end.

## Precautions Continued

- Do not install GenFlex Termination Bar to wood or other porous surfaces.
- At inside and outside corners, GenFlex Termination Bar must be cut and continued.
- GenFlex Termination Bar must be fastened a max. of 1" (25 mm) from each end of all sections.
- Eye protection is recommended when installing the appropriate fastener through the Termination Bar.
- Refer to Safety Data Sheets (SDS) for additional safety information.

## LEED® Information

Post-Consumer Recycled Content: 0%

Post Industrial Recycled Content: 0%

NOTE: LEED® is a registered trademark of the U.S. Green Building Council

Typical Properties	
Property	Typical Value
Material	Corrosion Resistant Aluminum
Thickness	0.0090" (2.3 mm)
Features	GenFlex logo on each section Reservoir channel for termination Caulk on top.
Holes	Pre-punched 0.28" x 0.38" (7 mm x 10 mm) Slotted Holes 3.93" (100 mm) o.c.

Please contact Amrize Technical Services at 800-428-4511 for further information.

This sheet is meant to highlight GenFlex products and specifications and is subject to change without notice. Amrize takes responsibility for furnishing quality materials that meet published GenFlex product specifications or other technical documents, subject to normal manufacturing tolerances. Neither Amrize nor its representatives practice architecture. Amrize offers no opinion on and expressly refuses any responsibility for the soundness of any structure. Amrize accepts no liability for structural failure or resultant damages. Consult a competent structural engineer prior to installation if the structural soundness or structural ability to properly support a planned installation is in question. No Amrize representative is authorized to vary this disclaimer.