



1. Intermediate securement is required on all vertical flashings in excess of 48" (1.2 m) for standard EZ TPO membrane flashings (non Peel and Stick) . For applications greater than 48" (1.2 m) but less than 8' (2.4 m), install the intermediate securement along a horizontal line halfway between the top of the wall or parapet and the finished roof surface. Repeat as necessary at 48" (1.2 m) intervals. Peel & Stick EZ TPO membrane flashings may be applied over an approved, primed substrate without height limitation without additional membrane securement.
2. Plywood or OSB securement to metal studs must be in accordance with industry standards and capable of preventing the plywood or OSB from warping or bowing. Special care should be taken to ensure tight and flush joints in the sheathing material. Securement must be achieved with an appropriate screw-type fastener versus nails in order to mitigate the possibility of fastener back-out.
3. Intermediate securement may be achieved with an inner-seam anchor bar as shown or by the application of the anchor bar through the flashing membrane. If the anchor bar is secured through the flashing membrane, it must be stripped-in with EZ TPO Reinforced membrane hot air welded to the flashing or EZ TPO Bar Cover Tape set in Clear Primer and caulked along the top edge.
4. GenFlex Anchor Bar intermediate securement will be secured at 12" o.c. (305 mm) into the approved substrate with the appropriate GenFlex fasteners.

For metal stud mounted substrates other than plywood or OSB, see Detail T-3.02.

Alternate securement method.

