

# GENFLEX PEEL & STICK™ TPO PIPE BOOT (WHITE)

# **Item Description**

**Item Number** 

White Pipe Boot

W590030036



## **Product Information**

# **Description**

GenFlex Peel & Stick TPO Pipe Boot is an injection- molded TPO boot with a pre-applied white butyl tape. The boot is specifically designed to be used in roofing applications for flashing of round penetrations. The pipe boot will fit various penetrations and shall be cut to the correct pipe diameter before installation.

Typical Properties		
TPO Property	Test Method	Typical Values
Color	n/a	White
Thickness	ASTM D 638	0.070" ± 0.003" (1.8 mm ± 0.07 mm)
Tensile at Break	ASTM D 751	1500 psi (10MPa)
Tear Resistance	ASTM D 751	350 lb/in (15 kN)

Tape Property	Test Method	Typical Values
Color	n/a	White
Thickness	Digital Gauge	0.030" ± 0.007" (0.76 mm ± 0.17 mm)
Solids	ASTM C 681	98%
Specific Gravity	ASTM D 71	0.97 ± 0.05
Cured State	n/a	Cured

### Installation

Refer to current GenFlex Technical Specifications for additional instructions.

IMPORTANT: GenFlex Clear Primer must be used on GenFlex White TPO membrane before applying GenFlex Peel & Stick TPO Pipe Boots.

- 1. Thoroughly mix GenFlex Clear Primer. DO NOT THIN! A minimum of 2 minutes of vigorous hand mixing with a wooden paint stirrer or its equivalent is required. All sources of ignition should be eliminated; adequate ventilation should exist.
- 2. Clean all surfaces with a clean cotton rag removing excess contamination prior to application of the primer.
- With a scrub pad and handle, apply GenFlex Clear Primer to the TPO membrane using long and continuous back and forth strokes with heavy to moderate pressure along the bonding area until no streaks or puddling occurs.
- 4. Allow GenFlex Clear Primer to dry until slightly tacky to a dry finger touch.
- 5. Cut the pipe boot to the desired diameter and slide down the pipe until the boot is approximately 2" (50 mm) above the deck sheet.
- 6. Remove the release paper from the underside of the pipe boot and apply the tape to the primed TPO surfaces.
- 7. Using a Teflon coated or hard rubber roller, hand-roll the tape into the primed surface assuring adhesion.

# **Product Data Sheets**



# **Application Precautions**

- 1. The substrate must be clean, dry smooth, free of sharp edges, tins, loose, or foreign materials, oil, grease, and other materials which may damage the flashing.
- 2. All roughened surfaces which could damage the flashing shall be repaired as specified to offer a smooth substrate. All surface voids greater than ½" (6 mm) wide, including reinforced TPO membrane and field sheets, shall be properly filled with like material.

#### **Product Data**

8 pipe boots per carton, 8 clamps, 2 scrub pads and 1 handle

# \*LEED® Information

Recycled Content

Post Consumer 0% Post Industrial 0%

\*NOTE: LEED® is a registered trademark of the U.S. Green Building Council.

# **Storage**

Store indoors in original unopened containers at a temperature between 60 °F and 80 °F (16 °C and 27 °C). Do not store on roof in direct sunlight or at temperatures above 100 °F (38 °C). When exposed to lower temperatures, restore to room temperature prior to use.

### **Shelf Life**

12 months; Shelf life will be shortened if exposed to elevated temperatures.

## **Precautionary Data**

- Avoid sources of punctures and physical damage. Take care when moving, transporting, or handling.
- Contact GenFlex Roofing Systems Technical Department for questions or specific recommendations.
- Refer to Safety Data Sheet (SDS) for additional information.

Please contact GenFlex Technical Services at 1-800-443-4272 option 1, for further information.

This sheet is meant to highlight GenFlex products and specifications and is subject to change without notice. GenFlex takes responsibility for furnishing quality materials which meet published GenFlex product specifications. Neither GenFlex nor its representatives practice architecture. GenFlex offers no opinion on and expressly disclaims any responsibility for the soundness of any structure. GenFlex accepts no liability for structural failure or resultant damages. Consult a competent structural engineer prior to installation if the structural soundness or structural ability to properly support a planned installation is in question. No GenFlex representative is authorized to vary this disclaimer.