
NOTE:

- REFER TO THE GENFLEX™ WEBSITE FOR THE MOST CURRENT INFORMATION.
- 2. HOLE IN MEMBRANE SHOULD EXTEND A MINIMUM OF 1/2" (12.7 mm) BEYOND CLAMPING RING AND SHOULD BE LARGER THAN THE DIAMETER OF THE LEADER PIPE.
- 3. INSULATION ADJACENT TO DRAIN TO BE APPROPRIATE GENFLEX INSULATION WITH APPROPRIATE BONDING SURFACE.
- GENFLEX WATERSTOP MIN 1/2 OF10 OZ. (295 ml) TUBE PER
 DRAIN. USE ADDITIONAL WATERSTOP FOR LARGER DRAINS.
- 5. IN RE-ROOF APPLICATIONS:
 - -REMOVE EXISTING FLASHING DOWN TO METAL BOWL.
 - -REPAIR OR REPLACE BROKEN DRAINS COMPONENTS.
 - -DRILL AND TAP BROKEN DRAINS BOLTS AND REPLACE IF NECESSARY.





OVERFLOW ROOF DRAIN WITH WATER DAM

ACCEPTABLE SYSTEMS: EZ TPO PEEL & STICK™

ACCEPTABLE SYSTEMS: EZ TPO PEEL & STICK™ SELF ADHERED

ISSUE / REVISION DATE:

MAXIMUM WARRANTY: 20 Years

05/01/2023

DETAIL NO.

EZT-PS-D-02

(800) 443-4272 www.genflex.com

NOT TO SCALE